



Casio LK-170 Key Replacement

This guide will walk you through the steps to replace a key or multiple keys on the keyboard of the Casio LK-170 .

Written By: Samantha Baker




INTRODUCTION

Key's stuck or broken? No problem. Replace sets of keys in no time with the help of a screwdriver.

TOOLS:


- [JIS Driver Set](#) (1)
-

Step 1 — Key



- i** You will be removing 17 11mm screws with a JIS-1 screwdriver to detach the back of the keyboard from the front.
- You will begin by removing 4 screws on each side of the piano, circled in red.
 - You will then remove the four screws that are a little hidden, circled in orange.
 - Next, remove the two screws in the middle of piano, as well as the three screws on the top of the piano, circled in yellow.

Step 2



- After flipping the keyboard over to the front, carefully remove the the front panel from the back panel of the keyboard using your hands.
- You should now see the screws holding the keys in place.
- ⓘ There are five 18mm screws per section of keys.
- With a JIS-1 bit, unscrew the five screws in the section with the key you want to replace.

Step 3



- You will be able to pick up the white keys with your hands and remove them.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 10:50:06 PM.